



670 New York Street
Memphis, TN 38104
www.chemicar.com

Tel: 800.261.7976
Fax: 901.274.8816
sales@chemicar.com

TOTAL COAT UNDERCOATING

APPLICATION AND CURING INSTRUCTIONS

1. CLEANING:

UC should be applied on a clean, primed or painted surface, free of oil, grease, dirt, release agents etc. A citrus based, waterborne degreaser (ie Citrikleen or Orange Blast) is recommended. Dupont's Final Klean (#3909S), an alcohol based paint prep, is also approved. Failure to properly clean and degrease the surface to be coated will result in the loss of adhesion and the dried coating will easily peel away in large sheets.

2. APPLYING:

UC has to be applied at a min of 50°F at a thickness of 0.5-1.0mm (20 to 50 mils). When applying with the RA/88 Economy gun, use 30 – 40 psi and hold the gun 12 to 14 inches away from the substrate. These are very crucial requirements. Do not guess, consult an accurate thermometer that is measuring in the spraying area. Temperatures do differ a lot from floor to ceiling. Be especially careful with opening of warehouse doors etc. which can bring in colder air.

Failure to apply at this min temperature or recommended thickness will result in the dried coating being cracked or easily removable (like black dust).

3. DRYING:

UC should not be exposed to temp below 50°F during the application and curing process. The drying process actually exists of three different steps: "dry to the touch", "fully cured" and "fully cross linked".

UC will be dry to the touch after:

- 90 min in ambient air of 72°F and RH 40% . More drying time might be required at higher RH.
- 30 min in a heated booth at 130°F (Allow 15 minutes flash-off at 72 F)
- 30 min (10 min flash off at 30" and 20 min full bake at 30") under Infra Red lamps.

UC will be fully cured after:

- 24 hours at ambient air of 72°F and RH 40%. More curing time might be required at higher RH.
- 60 min in oven at 130°F and a cool down period of 1 hr at 72°F.
- 40 min (10 min flash off at 30" and 30 min full bake at 30") under the Infra Red Lamps and a 1 hr cool down at 72°F.

UC will be fully cross linked after 7 to 12 days.

Curing times can be considerably improved by adding air movement (fan) to the drying method. Do not force dry at temps higher than 160F. For OEM high bake oven applications call 800 261 7976.

When the coating is "dry to the touch" the sprayed items can be moved, worked on, packaged etc. However they cannot be exposed to water and cold temperatures as this will cause thermal shock. Thermal shock will cause cracking of the coating and the UC will be easily removable, like black dust. Allow the coating to fully cure before exposing to water and cold weather. After the coating is fully cured, it can be painted. However during the next 7-12 days of cross linking, the coating will gain in hardness and strength. A fully cross linked coating has a hardness of: Shore A: 93-95.

4. STORAGE:

UC should be stored in a cool and dry place.